Rubber Floor Signs

Installation Instructions



Step 1 For best results, clean the designated area thoroughly with an alcohol based cleaner.



Step 2 Remove the quick peel liner from the back of the floor sign.



Step 3 Press the floor signs firmly to the floor to smooth out any air pockets.



Step 4 Tamp the area with at least 150lbs. of weight, using a soft (70 durometer) roller.

Features:

Smooth high gloss top coating that self cleans Proprietary heave duty rubber material Completely customizable high-resolution printing. Woven reinforcement increases durability and makes

removal fast and easy.



Check out our installation videos HERE.