

Floor Cleaning Products



Floor Degreaser

SKU: REM-102-Q

Main Purpose

Stripping floors of all paints, coatings, and adhesives to get down to a bare concrete surface.

Application Recommendations

For light to medium soils—Add 4 ounces per gallon of water. For heavy soils and floor machine application—Mix one part degreaser to one part water for tough to remove soils.

Strength

Mild: for cleaning surface grease and dirt.



Before



After



Adhesive Remover

SKU: REM-100-Q

Main Purpose

Removes adhesive without removing floor coatings.

Application Recommendations

Spray on the surface Let sit for 1–2 minutes.

Strength

Medium: will remove adhesive residue but not paint and epoxy coating.



Before



After



Paint Remover

SKU: REM-101-Q

Main Purpose

Removes build-up concrete floor coatings.

Application Recommendations

Apply a thick layer of up to 1/8 of an inch by pouring and brushing the product directly to the area being removed.

Strength

Extremely Strong: Removes sealer, acrylics, enamel, latex, urethane and polyurethane coatings.



Before



After

Floor Cleaning Products: Application Instructions

Insite Solutions Floor Degreaser

Concrete/Floors

Add four ounces of Insite Solutions Floor Degreaser per gallon of water. Apply freely to the floor or hard surface with a mop or scrub brush. Pick up and rinse with clean water.

Light/Medium Soils

Add four ounces of Insite Solutions Floor Degreaser per gallon of water. Apply to surface and allow to penetrate. A light scrubbing action will increase cleaning effectiveness. Rinse thoroughly with clean water.

Heavy Soils

Mix one part Insite Solutions Floor Degreaser to one part water for tough to remove soils. Apply to surface and allow to penetrate until soils have been loosened. Scrubbing actions will increase cleaning effectiveness. Repeat if necessary. Rinse thoroughly with clean water.

Floor Machine Application

Mix one part Insite Solutions Floor Degreaser to one part water. Apply freely to surface. Let sit 5–10 minutes before agitation surface with floor machine. Pick up and rinse with clean water.

Insite Solutions Adhesive Remover

Spray Insite Solutions Adhesive Remover on the surface. Let sit for 1–2 minutes. Heavy build-ups may require longer times or more Insite Solutions Adhesive Remover. Wipe clean with Insite Solutions Floor Degreaser or a damp cloth with water.

Caution: Insite Solutions Adhesive Remover may begin to remove paint from painted surfaces.

Newly formulated to meet California and OTC Standards.

Insite Solutions Paint Remover

Apply a thick layer of Insite Solutions Paint Remover to the coating to be removed by pouring, brushing or airless sprayer. If applying by brush do not apply as you would paint. Lay on a thick even layer up to 1/8 of an inch.

Don't brush or scrape the surface until the remover has had the time to work. Check the progress of the stripping action by using a scraper to see if the coating is softened down to the surface. If not, wait longer and recheck. As long as the remover is wet, it is working. Longer is better. Let the remover do the work.

Once the coating is softened, remove it with a scraper or other stripping tool. Reapply remover, if necessary. Repeat steps above.

After use, clean remaining thin residue with Insite Solutions Floor Degreaser, using a cloth or fibrous scrub pad. Allow surface to dry before further preparations.